

**DMX Input**

**DMX Loop Out**

Out 1 - 4

Out 5 - 8

Out 9 - 12

Out 13 - 16

**DMX10V**  
DMX to 10V Converter/Relay Driver

+12VDC Regulated  
Power Supply ONLY



**Power**

**Data**

**Pot Adjust**

1 2 3 4 5 6 7 8 9 10 11 12

| - DMX Start Ch - [S|A|H] |

S = Switch Mode Use "Switch"  
ON = Switch mechanical  
OFF = Variable relay's

A = Stand Alone  
ON = Pot Setting  
OFF = All Off

H = Hdwr Initialize  
ON = Initialize  
OFF = Normal

